



**30361 Faucet Installation**

1. Insert faucet body into sink. Mount rubber washer on the faucet before inserting.
2. Mount rubber washer and mild washer to faucet shank under sink. Mount lock nut to shank and hand-tighten. Note: Lock nut has provisions for various desk thicknesses. For standard thickness, apply lock nut with unthreaded portion first.
3. Rotate the spout to the left and right. Be sure the faucet is aligned properly. Make final tightening of lock nut.
4. Reconnect pull-out spray hose (5b) with the check valve assy (10) to the supply tube (4c), being certain that fiber (5c) remains in place in supply tube (4c) [tighten firmly].
5. Connect the supply hoses to the hot and cold water supply valves. Be sure to hold the supply hoses in place when tightening the nut so as not to twist the hoses.
6. Attach weight (5c) to hose (5b) on spout side of loop. Just above bend (use screws provided).
7. Confirm that faucet operating handle is in closed position and open supply valves. Check connections for leakage.
8. Disconnect spray head (9) from hose (5b) and flush hot & cold water lines until clear. Reconnect spray head (9), confirming that rubber washer (5d) remains in place.

PAR LIST 30361	10 Hose
10a	10a Hose
10b	10b Hose
10c	10c Hose
10d	10d Hose
10e	10e Hose
10f	10f Hose
10g	10g Hose
10h	10h Hose
10i	10i Hose
10j	10j Hose
10k	10k Hose
10l	10l Hose
10m	10m Hose
10n	10n Hose
10o	10o Hose
10p	10p Hose
10q	10q Hose
10r	10r Hose
10s	10s Hose
10t	10t Hose
10u	10u Hose
10v	10v Hose
10w	10w Hose
10x	10x Hose
10y	10y Hose
10z	10z Hose

